


# Geovista Platform Logger

Software Operations

**V 7.4**



## Table Of Contents

Introduction .....	4
GeoVista Platform Logger (GVPL) Short Cut keys .....	4
Add A Sonde Serial Number .....	4
Possible problems With Add Sonde Serial Number .....	5
Build A Stack .....	6
Select Number Of Sondes.....	6
Select Sonde Types & Serial Number .....	7
Apply Stack Description.....	7
Saving The Stack Definition.....	7
Possible Problems With Building A Stack .....	7
Select A Stack .....	8
Screen Shot: Selection Of Stack .....	8
Problems That Can Occur With Stack Selection. ....	9
Sonde Diagnostic Data Display .....	9
Powering The Sonde Stack.....	9
Screen Shot: Sonde Power Supply & Battery Display .....	10
Selecting Diagnostic Display.....	10
The Data Quality Report.....	10
Screen Shot Diagnostic Data Display.....	11
Select Cable Length.....	11
Timebase .....	11
Calibration .....	12
Average .....	12
Select Sonde For Display .....	13
Stack Information Window. ....	13
Screen Shot Stack Information Window .....	13
Select A Log File For Data Recording .....	13
Starting To Record Data.....	14
Log Direction.....	14
Sample Interval Selection.....	15
English & Metric Depth Systems .....	15
Starting Logging.....	16
Discussion Of Displayed Screen .....	16
Display Of Diagnostic Data While Logging.....	16
Sonde Power & Battery Condition Display .....	16
Screen While Logging Up With Diagnostic Panel Displayed .....	17
Display Of Depth And cable Speed With Optional tension.....	17
Replay Of Logged Data.....	17
Display Of Logged Data.....	17
Curve Ident On Each Page.....	18
Deepest & Shallowest Depths .....	18
Full Depth Range.....	19
Plot To Printer .....	19
Footer On Each Page .....	19
Vertical Scale.....	19
LAS File Options.....	19
Automatic LAS File Generation. ....	23
Editing Curve Presentation .....	26
Selection Of Sonde .....	26
Curve Position On The Log display .....	26
Curve Display Values.....	27
Curve Display On And Off.....	27
Filter Width .....	27
Trace Colour.....	27


Saving Of The Curve Parameters .....	27
Header Editor .....	28
The Standard header .....	28
Editing The Header Entries .....	29
Editing The Header Fixed text.....	29
Recommendations On Use Of Headers .....	29
Log Disclaimer .....	30
Sonde Data Calibration.....	30
Number Of Calibration Points .....	31
Averaging Period For The Calibration .....	31
Density Sonde Calibration.....	32
Starting The Calibration .....	32
Graphical Display Of The Calibration.....	32
Saving Calibration Data To File .....	33
Winch Parameters.....	33
Depth System Parameters .....	33
Winch version.....	33
Tension Units Kgs or Lbs .....	33
Depth Units-feet Or Metres .....	33
Reverse SE Sense .....	34
Measure Wheel Circumference & Depth Pulses Per Revolution.....	34
Depth System calibration.....	35
Set Depth .....	36
Increase.....	36
Decrease .....	37
Set Depth .....	37
Zero The Depth.....	37
Set Stack Length.....	37
Auto Depth generation .....	37
Cable Tension System calibration. ....	37
Cable Tension Alarm.....	38
Tools Menu.....	39
Log File Depth Shift .....	39
Log File Splice .....	40
Density Logging With The GeoVista System .....	41
Enabling & Disabling The Density In Grams\CC .....	41
Master Calibration. ....	42
How Is The Master Calibration Applied?.....	44
Sonde Normalisation .....	44
Data Flow While Logging .....	46
Notes On The Calibrators. ....	46
Version 2 Logger & Sonde Communications Control.....	47
Set Current Limit .....	53
Set Threshold.....	53
Software Modification Record .....	53
Manual Modification Record.....	55

## Introduction

This manual describes the function and operation of the GeoVista data acquisition and replay software. All the necessary functions are described allowing the user to learn the operation of the software.

### GeoVista Platform Logger (GVPL) Short Cut keys

The software has a set of icons which allow rapid access to the most commonly used functions, and are referenced throughout the text of this manual. The short cut icons are;



The function of these icons is indicated below each icon. Other short cut keys are

Short Cut key	Function
F1	Open new logging file
F2	Open file for replay
F3	Edit standard header
F4	Edit existing header
F5	Select sonde stack
F6	Open winch control panel
F7	Open sonde diagnostic panel
F8	Toggle sonde power


In addition, each of these functions is selectable from the top menu in the usual way. In this manual, selection of functions is normally described by reference to the menus rather than the icon, so the sonde power function would be described as **System->Sonde Power**

### Add A Sonde Serial Number

The GeoVista Platform Logger Software (GVPL) is aware of the sondes that are owned in a particular location. A list of these sondes, and their serial number, is held within the GVPL database files.

If the user wishes to add a sonde to the GVPL installation then a simple procedure needs to be followed. These steps are as follows

From the top menu select **Select->Add Sonde Serial Number**. The screen will appear as;



Here the user has scrolled down the scroll box labeled “Sonde Types Registered” to locate the name of the new sonde, TCME, and has entered the serial number of the sonde into the box labeled “Enter Serial Number”, in this case the serial number is 1553.

When **Accept Sonde** is pressed, the GVPL will update the database files and the sonde will be available for use in a stack.

When a new sonde is purchased, then a calibration file will be made available with the sonde. For the system to correctly calibrate the sonde data then this calibration file must be correctly located into the directory c:\gvsystem. Copy the supplied calibration file into this directory.

The calibration filename is created in a special way. So that the system can correctly determine which calibration file to apply. For example, with the sonde being registered above, the calibration file name will be

TCME1553.CAL

Clearly, the filename is a concatenation of the sonde name (TCME in this case) and the sonde serial number (1553 in this case). The file extension is always CAL.

So, if the system is made aware of the sonde name and serial number the calibration filename can be constructed by the GVPL and applied to locate the correct calibration file.

Possible problems With Add Sonde Serial Number

It is possible that when scrolling down to locate the name of the new sonde from the list that it cannot be located. The reason for this is that the files GV\_SONDE.INI and GV1SONDE.INI, both located in directory c:\gvsystem, are out of date.


If this occurs then check carefully on the supplied disc that there is not a new copy available. If there are new copies available then copy these into the directory c:\gvsystem. It is a good precaution to make copies of the old files before they are overwritten.

If new copies of these files are not available then please contact GeoVista for further assistance.

## Build A Stack

Before the sondes can be operated, then it is necessary to build a stack. This is the method by which the GVPL is informed of the combination of sondes that are to be run, which serial numbers are to be used and in which sequence the sondes are to be connected.

To activate this procedure, **Select Sonde->Build Stack** from the top menu. The screen will appear as;



### Select Number Of Sondes

The first task is to tell the system how many sondes are to be in this stack, and this is achieved by selecting a value between 1 and 5 in the "Select Number Of Sondes In Stack" selection box. In the example shown, the user has selected three.

On making this selection, the display in the adjacent window will change to show placeholders for the number of sondes selected to be in this stack.

#### Select Sonde Types & Serial Number

In the window labeled “Stack Diagram”, locate the scroll boxes under the label “Sonde Type”. Starting with the top box, which will be the sonde at the top of the stack or the shallowest sonde, select the sonde name required. In this case the user has selected “ELOG” as the top sonde.

In the scroll box to the right of the sonde selected, another selection box appears under the column labeled “Serial #”. When opened, this will display a list of sonde serial numbers of type “ELOG” that are registered with the system. Select the required serial number.

Repeat this process for the other two sondes. In the example shown the user has selected the stack:

ELOG Serial number 1087  
NGRS Serial number 1085  
TCME Serial number 1142

#### Apply Stack Description

In the window labeled “Stack Description”, the user can enter free text that will be a useful reminder of the sondes in the stack that has been defined.

There are no restrictions of required format for this text, the GVPL does not use this data in any way, it is simply displayed when the user selects a stack in future. For example, the text “BLUE Stack” has been included and reflects the use of colour coded stacks in some locations.

#### Saving The Stack Definition

When the appropriate data has been entered, press the button labelled “Save Stack Definition” and the stack definition will be saved to the system database.

Pressing “Cancel” at any time will exit the screen and discard any data that has been entered.


#### Possible Problems With Building A Stack

When trying to locate the sonde name required in the “Sonde Type” selection box, the required name may not appear. The reason for this is that the sonde type has not been registered. Perform the procedure detailed in the section “Add A Sonde Serial Number”.

Similarly, if the sonde type can be located but the required sonde serial number is not present in the “Serial #” selection box, perform the procedure detailed in the section “Add A Sonde Serial Number”.

## Select A Stack

Prior to testing a stack or starting logging, then the GVPL needs to be informed of the stack, which is to be run. This is achieved by selecting **Sonde-> Select Stack** from the top menu. The screen will appear as below;



Screen Shot: Selection Of Stack

Note that this is a common operation, a shortcut key has been made available, and is high lighted in the picture above. Simply clicking on this will show the stack select screen.

In the selection box all the stacks that have been built on this system will appear, and the user selects the required stack. Here the stack built in the previous section has been selected.

Note that the sonde serial numbers are as entered before and the comments that were entered have also appeared.

After displaying the appropriate stack, click on “Accept Stack Selection” and the screen will close with the correct stack selected.

The button labelled “Accept Last Stack Used” is also available, and simply selects the last stack that was selected. This is provided as a convenience to speed operations



## Problems That Can Occur With Stack Selection.

Any problems that occur here will be related to an error on one of these files;

GV\_SONDE.INI  
GV1SONDE.INI  
GV\_STACK.INI

If problems occur then reinstall these files from the distribution discs. Reloading GV\_STACK.INI will cause any recently built stacks to be lost so it is best to copy GV\_SONDE.INI & GV1SONDE.INI first to see if this clears the problem.

## Sonde Diagnostic Data Display

### Powering The Sonde Stack

At this point, the following steps will have been performed;

- 1 The required sondes will have been added to the sonde database
- 2 The required stack will have been built
- 3 The required stack will have been selected
- 4 The sonde stack will have been connected to the winch and the logging box correctly connected.

The next step is to apply power to the sonde stack. This is achieved by selecting from the top menu **System->Sonde Power**. This will send a command from the GVPL to the logger box, which then applies sonde power to the sondes.

Note that, as switching sonde power is a common function, there are three methods of switching the sonde power on and off. The menu selection **System->Sonde Power** is probably the least convenient.

Pressing **F8** on the keyboard will toggle the power supply, so that if the sonde power is on, it will switch off when **F8** is pressed and vice versa.

Clicking on the short cut key with the yellow “lightning strike” at the top of the tool bar short cut band (see [Screen Shot: Selection Of Stack](#) above) will also switch on and off the sonde power supply.

The logger box measures the sonde power supply voltage and current and reports these values back to the GVPL for display. These are displayed in the top left hand corner of the screen display, and are reproduced below enlarged for clarity.



#### Screen Shot: Sonde Power Supply & Battery Display

Here, the sonde is taking a current of 52milliAmperes, and the voltage applied is 68VDC. Note that the voltage measured is the voltage at the surface, and will be lower at the cable head as there will be a voltage drop across the logging cable.

Also measured is the power supply to the logger. This is nominal 12VDC, but satisfactory operation down to 10.5VDC can be achieved.

#### Selecting Diagnostic Display

Now the sondes are powered, the diagnostic panel can be entered to ensure correct operation of the sondes prior to logging. This is not an essential step, but it is highly recommended.

Again, because this is a common operation, there are three methods of displaying the diagnostic panel. Each will achieve the same result, but some are more convenient than others depending on circumstances. The three methods are;

- 1 Select **System->Diagnostic** from the top menu.
- 2 Press **F7** on the keyboard
- 3 Click on the icon with the spanner display on the top tool bar short cut band


The display will now appear as in the screen shot below.

There are several areas of interest here, and they will be discussed separately.

#### The Data Quality Report

The window, coloured green in this display, indicates the quality of the telemetry coming from the sonde. Each data packet from the sonde has error checking data attached to it, and this enables the GVPL to determine if an error has occurred. If an error is detected then the green dot will be replaced by a red dot, and the data packet discarded.

A count of good and bad packets is maintained in the windows labelled "Bad Packets" and "Good Packets". These are for the user to monitor. These values can be reset by clicking on "Reset Counters".



Screen Shot Diagnostic Data Display

The data in these windows is for the users information only, no use of made of this data by the system.

On a system in good condition, there should be no red packets although an occasional red packet can be expected in an electrically noisy environment. As the GVPL discards any bad packets, their presence will not cause an error in the recorded data.

In the event that red packets become significantly more in number, then this is an indication that a problem is developing and corrective action should be taken before the situation becomes critical.

### Select Cable Length

The surface logger box has an amplifier to amplify the digital telemetry signal from the sonde, and the gain of this amplifier can be used to select high gain (for longer cables) or low gain (for shorter cables). In fact, the telemetry is quite tolerant of cable length and the telemetry will be good (all green packets) on either setting. If, during a logging operation, red packets become more frequent then it may be possible to save the situation by increasing the gain.

### Timebase

Normally, users require borehole logs to be referenced against depth, and this is what the GeoVista logging system produces. On the other hand, the cable communications protocol is time based. What this means is that once the stack in use has been declared and logging is started, the stack is addressed on a timebase. Each sonde is addressed in turn at a regular interval. The frequency with which the stack is interrogated is variable, under user control, at rates of 10, 20 or 40 samples *per second*.

What this means is that if 4 sondes are in the stack and the highest sample rate of 40 samples per second is chosen, then each sonde will be interrogated 10 times per second. To relate this to depth, this will give a sample *from each sonde* for each centimeter of borehole traveled if the logging speed is 6 metres per minute.

If only 2 sondes were in the stack, then 1 centimeter sampling would be achieved at 12 metres per minute.

The sample rate is set by the options available in the “Timebase” section. The values available are as in the table below.

Timebase Selection	Samples per second
100 milliseconds	10
50 milliseconds	20
25 milliseconds	40

The user should decide on what vertical resolution is required and the number of sondes in the stack and what logging speed should be used. If unsure, use 25 milliseconds. The only downside of this is that the data files will be larger.

## Calibration

As discussed previously, each sonde has an associated calibration file which converts the raw data from the sonde into the required engineering units. When the check box labelled “Calibration” is checked, then these calibration coefficients will be applied and the data displayed will be in engineering units. When the “Calibration” box is unchecked, then the data display will be raw data as received directly from the sonde.

## Average

When the “Average” checkbox is checked, then data from the sonde will be accumulated over the period starting when the box is checked, and the data displayed will be the average value over that interval. This is useful with radiation sondes.


## Select Sonde For Display

In the diagnostic data display, the data for the ELOG sonde is displayed. The complete stack comprises three sondes, as seen in the stack information window (see next section). To display the data from other sondes in the stack, select the sonde from the selection box labelled “Select Sonde For Display”.

All the sondes in the stack will be displayed and can be selected for display as is the ELOG in the example.

## Stack Information Window.

In the top center of the screen is the stack information window, shown below enlarged for clarity.



Screen Shot Stack Information Window


There are two lines of information here, the upper line displays the currently selected log file name (none selected as yet in the above example) and the lower line shows the names of the sondes selected and the total sonde length. This useful in setting the sonde depth in the borehole, and will be referenced later.

## Select A Log File For Data Recording

Prior to logging, the user must specify the name of the log file where data will be stored. Entry to the logging mode is prohibited until a filename has been entered by the user. This operation is initiated by pressing the icon showed on the screen below.

The shortcut icon is indicated, and after this the usual Windows file naming procedures are followed. The ability to navigate directories and create new directories exists at this level.

Enter the new filename in the location as indicated. If the filename entered already exists the user will be warned of this and the creation of a new file will be disallowed. This prevents overwriting existing data in error.



After successful creation of the new file, the stack information window will be updated as below.




## Starting To Record Data

There are several options when recording data, some are cosmetic and some are essential that they are correct.

### Log Direction

Firstly, the log direction must be set correctly. There are three modes of logging, these being Log Up, Log Down and Log Time. Most services are recorded in either log up or log down, although log time has some applications.

On the top bar of the GVPL screen, locate the drop down box as shown below.



Here, the drop down box has been activated, and the three options are displayed. Select the log direction required and the selected mode will be displayed. It will not change unless the user selects a different mode.

### Sample Interval Selection

The selection of the sample interval is a cosmetic selection, in that the value selected here does not influence in any way the data that is acquired from the sondes and recorded to disc. On replay, the user has all options available independent of the value chosen during logging.

What is does do is control how much of the logged interval is displayed on the screen while logging. Usually, a value of 10cm gives the best display, and is a good starting point. The user may modify the value chosen in light of practical results.

The selection is made by the drop down box shown below.



### English & Metric Depth Systems

The GVPL can operate in either English (Feet) or Metric (metres) depth systems. If the English mode has been selected then the sample intervals available will be in inches. All other comments for the metric system apply.

## Starting Logging

When logging is initiated, the following steps, all of which have been described so far, should have been performed;

- 1 Assembly of the sondes required
- 2 Selection of the appropriate stack
- 3 Powering the sondes and checking that the data is correct
- 4 Selection of a log file name
- 5 Selection of the log direction mode
- 6 Selection of the sampling interval

When these steps have been performed, logging is initiated by pressing the “Start Log” icon (this is the icon on the top row with the red circle).

When the sondes are pulled uphole (log up was selected) then the display will be as follows.

### Discussion Of Displayed Screen

One of the special features of the GVPL is that the performance of the whole system is monitored, and made available to the user while logging. Some of these points are brought out here.

### Display Of Diagnostic Data While Logging

The first thing to notice is that the operator has also opened the diagnostic screen and resized the display to show both the diagnostic data and the logged data simultaneously. This is a powerful and useful feature of the GVPL system, it allows all available data to be displayed to ensure data quality.


For example, if cable head problems were developing then this may well be displayed as red packets. The user would be aware of this and could take corrective action, for example increase the telemetry amplifier gain, or perhaps choose to pullout and check the cable.

### Sonde Power & Battery Condition Display

Here the sonde current is displayed, again allowing the user full knowledge of what is happening with the sondes.

The battery supply to the logger is also displayed, allowing more information to be used as a system diagnostic.





Screen While Logging Up With Diagnostic Panel Displayed

## Display Of Depth And cable Speed With Optional tension


The display above shows the sonde depth and cable speed. This is essential information. Also available when used with a GeoVista winch system is the cable tension. The example above does not have this option.

## Replay Of Logged Data

The replay function of the GVPL allows the following features;

### Display Of Logged Data

To view the logged data on the screen, select the **File->Open replay File** and select the log file name as required. The screen will now look like this;



Screen Display Of Temperature-Inclinometer Log

These are numerous options and controls here, and a brief description will be given. The best method of understanding the operation is to get a sample log and try the different options.

### Curve Ident On Each Page

This allows the appearance or suppression of the curve description on each page. Useful when continuous stationery is used in the printer.

### Deepest & Shallowest Depths

The user has the option to display & print out a selected interval by entering the depth limits in these boxes. The actual log file limits are displayed in another pair of boxes which cannot be edited.

### Full Depth Range

Pressing this simply resets the log depth file limits to the full extent of the logged interval.

### Plot To Printer

This initiates the log to be plotted to the selected printer.

### Footer On Each Page

This causes the log file name to be printed at the bottom of each page of the printed log.

### Brief header On.

This causes the printing of the brief header. This comprises the title line from the header file to be written to the printer prior to the plotting of the log. This is a shortened version of the main header and is useful for field prints.

The font for this printout can be selected from **System->Brief Header Font**.

### Vertical Scale

This allows control of the vertical scale for the print out and the screen display.

Some printers do not print exactly the correct vertical length of paper, which can be a problem for log correlation. The solution to this is to select **System->Printer vertical Scale** and enter the appropriate correction.

### LAS File Options

To export the logged data to other software packages, for example Viewlog or Wellcad, the data needs to be presented in a suitable format. The format chosen is the LAS (Log Ascii Standard). The options here allow control of the exported data.

Note that only GeoVista software can read directly the recorded data files, the translation to LAS is required for all other software packages.

There are options available for the LAS translation. These are the inclusion of the Recorded cable tension (when fitted) and the sonde power during logging.

In the event that a user curve has been included, then this data can also be exported.


Selecting the “Displayed Data Only” box will cause only the curves actually displayed on the replay log screen to be output to the LAS file. If not clicked, then all the curves in the log file will be exported.

On GVPL version 5.80 & later, the ability to export sonic full wave data as a <>.WAF file is available. In the “LAS File Options” frame, the options FWS5 and FWS3 will appear when a sonic log is replayed. Clicking either of these before creating the LAS file will cause the creation of two files in the same directory as the LAS file. If the name given for the LAS file, was for example, “myfile”, then the two extra files (if both options were selected) will be

Myfile\_3FT.WAF and Myfile\_5FT.WAF

These are Ascii files which can be read into WellCAD using the file import routines. Once imported into WellCAD then the built in sonic processing options can be used.

On GVPL version 5.84 & later, further options are available. These are selected from the LAS File Options, as seen below.



When a full wave sonic record is detected in the data file, then the extra options to the right of the option box will appear. Selecting either, or both as shown, of FWS5 and FWS3, will allow export in a format usable to other packages. Ticking the WellCAD box will export the <>.WAF file as described above. Ticking the ViewLog box will export the files in the SEG2 format. This format can be read both by WellCAD and ViewLog.

The files created will be, from an input file of myfile, myfile\_3FT.SG2 and myfile\_5FT.SG2. They will be created in the same directory as the LAS file.

Version 6.34 & later rationalized the full wave sonic export into a single SEG2 output. This is an international standard that is supported by numerous commercially available packages.

Note that if a Windows association is setup, the double clicking on either a <>.HDR or <>.RDF file will start a new copy of the GV Platform Logger (version 6.34 & greater) and enter the replay screen automatically.

GV Platform Logger version 6.45 and later now have a facility to associate header file entries with specific fields in the LAS file. This allows the creation of header templates in the importing software to automatically associate header entries in the GV header file and the headers created in the importing software.

This is achieved by editing the GV\_HEAD.INI file. An example of this file is shown here.

[Header Description]

Number Of Entries=1

Entry 1=GeoVista

[GeoVista]

Number Of Fields=33

Logo=C:\vb\_proj\Q\_Log\GVLog2.bmp

Entry 0=SERVICE COMPANY/,/Induction/,/

Entry 1=COMPANY/,/BLS Logging/,/

Entry 2=COUNTRY/,/Jordan/,/

Entry 3=PROVINCE/,/Conwy/,/

Entry 4=WELL/,/KZRC\_0616\_1/,/

Entry 5=FIELD/,/Burton/,/

Entry 6=LOCATION/,/In The Truck/,/

Entry 7=STATE/,/Cheshire/,/

Entry 8=COUNTY/,/England/,/

Entry 9=LATITUDE/,/1234/,/

Entry 10=LONGITUDE/,/5678/,/

Entry 11=ELEVATION/,/10 metres/,/

Entry 12=PERM. DATUM/,/GL/,/

Entry 13=DATE/,/09/05/10/,/

Entry 14=SALINITY/,/NaCl/,/

Entry 15=RUN NUMBER/,/1/,/

Entry 16=DEPTH DRILLER/,/300/,/

Entry 17=DEPTH LOGGER/,/299/,/

Entry 18=TYPE OF FLUID/,/water/,/

Entry 19=DENSITY/,/1.0/,/

Entry 20=VISCOSITY/,/3/,/

Entry 21=END CIRC./,/1980/,/

Entry 22=UNIT NUMBER/,/1/,/

Entry 23=RIG NUMBER/,/2/,/

Entry 24=oh-csg 1/,/30 meters/,/

Entry 25=oh-csg 2/,/40 metres/,/

Entry 26=oh-csg 3/,/50 metres/,/

Entry 27=oh/,/60 metres/,/

Entry 28=remarks/,/Warm day/,/

Entry 29=RECORDED BY/,/MP/,/

Entry 30=Start time/,/0900/,/

Entry 31=End time/,/1100/,/

Entry 32=WITNESSED BY/,/Local People/,/

[mnemonic]  
mnemonic 0=/SRVC./  
mnemonic 1=/COMP./  
mnemonic 2=/CTRY./  
mnemonic 3=/PROV./  
mnemonic 4=/WELL./  
mnemonic 5=/FLD./  
mnemonic 6=/LOC./  
mnemonic 7=/STAT./  
mnemonic 8=/CNTY./  
mnemonic 9=/LATI./  
mnemonic 10=/LONG./  
mnemonic 11=/ELEV./  
mnemonic 12=/PERM./  
mnemonic 13=/DATE./  
mnemonic 14=/SALI./  
mnemonic 15=/RUN./  
mnemonic 16=/OTHER./  
mnemonic 17=/DEPT./  
mnemonic 18=/TYPE./  
mnemonic 19=/DENS./

Note that the first part of this file is edited using the usual GV header editor. The user must enter the section below the keyword [mnemonic]. The correlation between the two sections is the Entry number and the mnemonic number. For example, Entry 15 Run Number will be exported into the LAS file with the mnemonic RUN.

Using the sample file, then the Well Information section of the LAS file will be as below.

```
#-----
~Well Information Section
#MNEM.UNIT      VALUE.NAME      DESCRIPTION
#-----
STRT.M  973.72      :START DEPTH
STOP.M   880.00     :STOP DEPTH
STEP.M   -0.01      :STEP
NULL.   -999.25     :NULL VALUE
SRVC.    Induction  :SERVICE COMPANY
COMP.    BLS Logging :COMPANY
CTRY.    England    :COUNTRY
PROV.    Conwy       :PROVINCE
WELL.    ABC_0616_1  :WELL
FLD.     Burton      :FIELD
LOC.     In The Truck :LOCATION
STAT.    Cheshire    :STATE
CNTY.    England     :COUNTY
LATI.    1234        :LATITUDE
LONG.    5678        :LONGITUDE
```


ELEV.	10 metres	:ELEVATION
PERM.	GL	:PERM. DATUM
DATE.	09/05/10	:DATE
SALI.	NaCl	:SALINITY
RUN.	1	:RUN NUMBER
OTHER.	300	:DEPTH DRILLER
DEPT.	299	:DEPTH LOGGER
TYPE.	water	:TYPE OF FLUID
DENS.	1.0	:DENSITY
VISC.	3	:VISCOSITY
OTHER.	1980	:END CIRC.
OTHER.	1	:UNIT NUMBER
OTHER.	2	:RIG NUMBER
OTHER.	30 meters	:oh-csg 1
OTHER.	40 metres	:oh-csg 2
OTHER.	50 metres	:oh-csg 3
OTHER.	60 metres	:oh
OTHER.	Log started Wednesday, Mar 23 2011 15:4:	
OTHER.	MP	:RECORDED BY
OTHER.	0900	:Start time
OTHER.	1100	:End time
OTHER.	Local People	:WITNESSED BY
UWI.	0000	:UNIQUE WELL ID

When creating the [mnemonic] section of the GV\_HEAD.INI file take care to respect the layout otherwise the results may not be as expected.

### **Automatic LAS File Generation.**

With version GV Platform Logger Version 6.34 & later, it is possible to have the LAS file generated immediately on stopping the logging process.

To achieve this, there is a set of options accessed by the **File->Setup LAS Output** from the top menu. The screen displayed is shown here;



The function of these boxes is;

#### Generate LAS Automatically After Logging

When ticked, the LAS file will be generated as the Stop Log button is pressed.

#### Displayed Data Only

When ticked, only curves on log display will be exported to the LAS file

#### SEG2 Sonic Export

When ticked the creation of SEG2 files will be created. Note that this is only operational with sondes with mnemonic ASNC,CBL5 and SNIC. Also the adjacent drop down box allows the selection of 5cm or 10cm sampling interval for these files.

#### Computed Curves



When ticked, and computed curves present will be exported to the LAS file.

#### Cable Speed

When ticked, the cable speed during logging will be exported to the LAS file.

#### Cable Tension

When ticked, the cable tension during logging will be exported to the LAS file.

#### Cable Speed

When ticked, the cable speed during logging will be exported to the LAS file.

#### Sonde Power

When ticked, the sonde stack power (Voltage & Current) during logging will be exported to the LAS file.

#### Logger Supply

When ticked, the logger power supply voltage during logging will be exported to the LAS file.

#### Regular Log Sample Interval

Here the user has the option to select 1cm, 5cm or 10cm sample interval for the LAS file depth column.

The output LAS file will be stored in the same location as selected during for the log raw data files, and have the same name. The file extension will be LAS.

For the sonic files the files generated will be as follows

Sonde mnemonic	
ASNC	<>_RX1TX1_2FT.SG2 <>_RX2TX1_3_3FT.SG2 <>_RX3TX1_5_1FT.SG2
CBLS	<>_RX1TX1_3Ft.SG2 <>_RX2TX1_5Ft.SG2
SNIC	<>_RX1TX1_3FT.SG2 <>_RX2TX1_5FT.SG2 <>_RX2TX2_3FT.SG2 <>_RX1TX2_5FT.SG2


Where <> represents the originally selected path for the recorded data. Note that the spacing is embedded in the extended file name.

The LAS file generation options selected are stored in the GV\_SYS.INI file and will be recalled each time the software is started.

## Editing Curve Presentation

During both logging and replay, it is possible to modify the curve presentation. In both scenarios the method is the same.

To initiate the curve editor, double click on the log display area and the “Edit Curve Appearance” dialog box will appear as below.



Edit Curve Dialog


## Selection Of Sonde

In a stack system, there may be several sondes. Select the sonde which is required to be edited from the drop down box. In the sample shown the NGRS (gamma sonde) is shown selected.

Selecting the different sondes in the stack will automatically display the appropriate channel names and units for the selected sonde.

## Curve Position On The Log display

The usual log grid is divided into three tracks, termed Track1, Track2 and Track3 as seen below.



A curve has a LH (Left hand) position and a RH (Right hand) position, and these values are chosen from the drop down menu as seen in the edit curve dialog. Using these positions, a curve can be placed over a single track or over two or more tracks. Curves can be placed over the depth track, if required. Many possibilities are available and the user should investigate these.

### Curve Display Values

The user can enter the LH and RH curve values to suit the application. There is complete flexibility in the values that can be applied.

In the event that the data value goes above the RH value set (or below the LH value set) then automatic curve wrap will occur.

### Curve Display On And Off

The CURVE drop down box will allow the curve to be turned off from the display (select the “OFF” option) or have a number from 1 to 4 assigned to the curve.

In logging, the value of this number has no effect. During replay (both to the screen and the printer) it is used to thicken the lines of the trace. This is useful for different printers and to distinguish between different traces on monochrome printers.

### Filter Width

The filter width control allows smoothing of data to suit the type of data being recorded. For example, the gamma data requires a filter of typically 17, whereas the temperature curve does not require a filter width.

### Trace Colour

The colour of each trace can be individually set by selecting the colour option. This feature is used to distinguish between different curves placed in the same track.

### Saving Of The Curve Parameters

If, during a logging session, the user modifies the curve parameters, a prompt will be raised asking if these options



Answering “Yes” to this will save the modified presentation into the log file header and into the system database files. The saving of the parameters in this way ensures that after one operation the required local format will be written to the sonde database and automatically used for each new log. This feature allows adoption of local log presentation standards with minimal effort.

## Header Editor

It is required to record textual information about the circumstances of the logging operation, and present this information in the form of a printed log header. The GeoVista system allows the creation of a user defined log header and the editing of this header

### The Standard header

The system has a standard header stored in the database, and this is used as the template for the headers that the user will create and print out with the log.

Selection of **System->Edit Standard Header** will open this standard header or template, and allow the user to edit the contents.

When the user later creates a new log file, a new header is automatically created. The contents of this newly created header (which will have the same name as the log file, but with a different extension) will be copied from the standard header. To later edit a created header (rather than the standard header) requires the selection of **System->Edit Existing Header**.

		Company: <input type="text" value="Water Co Ltd"/> Client Name: <input type="text"/> Services: <input type="text" value="FLOWMETER GAMMA"/>	
Client: <input type="text" value="Conwy Council"/> Well Name: <input type="text" value="Burton #1"/> Field: <input type="text" value="Cheshire"/> Country: <input type="text" value="UK"/> Latitude: <input type="text" value="NA"/> Longitude: <input type="text" value="NA"/>	Other Services: <input type="text" value="None"/> Log Datum: <input type="text" value="GL"/> Drill Datum: <input type="text" value="GL"/> Perm Datum: <input type="text" value="GL"/> Elevation: <input type="text" value="100Metres ASL"/>		
Date: <input type="text" value="May 2001"/> Run #: <input type="text" value="#1"/> Type Of Log: <input type="text"/> Depth Driller: <input type="text"/> Depth Logger: <input type="text"/> Fluid In Hole: <input type="text"/> Salinity: <input type="text"/> Density: <input type="text"/> Fluid Level: <input type="text"/> Maximum Temp.: <input type="text"/>	Logging Engineer: <input type="text" value="S. Fletcher"/> Logging Unit: <input type="text" value="GV1"/> Witness: <input type="text" value="Client"/> Rig Operator: <input type="text" value="Acme DrillCo"/>  Comments: <input type="text" value="logged up 0900"/> <input type="text"/> <input type="text"/> <input type="text"/>		

Sample Of Header

### Editing The Header Entries

The text in blue is the data that the user normally modifies, and this is what will be printed onto the log at print time. Note that a logo has been included in the top right hand corner. The user can create a logo personalized to their system by scanning in their logo and creating a bitmap image. Double clicking on the logo area will allow the location and inclusion of the bitmap image.

Some experimentation may be required to get the printout to be a satisfactory size.

### Editing The Header Fixed text

The user may also modify the text which appears in black in the above example. This is done by double clicking on the text field of interest. A dialog box will appear allowing entry of the new text.

This allows both personalization and changing to different languages.

### Recommendations On Use Of Headers

The best method of handling the headers is to follow these steps;

On a new system.

- 1 create the logo for the users organization and check that it prints out well on the chosen printer.
- 2 Edit the fixed header text on the standard header to reflect local needs and save these to the standard header.

#### When on logging jobs

- 1 Before the first run, enter all the available data to the standard header so that this data will be automatically copied to headers as they are created during the logging operation.
- 2 Add new information as it becomes available, editing the previously recorded headers as necessary.
- 3 Make sure that the headers are correctly filled in. It may seem unnecessary bureaucracy at the time, but can prove vital at a later date.

#### Log Disclaimer

On GVPL Version 5.2 and later, an option exists to optionally include a disclaimer on the header print out. This disclaimer is stored in the GV\_HEAD.INI file, and may be edited by the user. The standard text, in the format seen in GV\_HEAD.INI, is;

[Disclaimer]

Line 1= Company Disclaimer

Line 2= All interpretations are opinions based on inferences from electrical

Line 3= or other measurements. The Company does not guarantee the correctness

Line 4= of these interpretations. The company shall not be

Line 5= responsible for any loss, however incurred, in the use of these inferences.

#### Sonde Data Calibration

The sondes often produce data which needs conversion from raw data to engineering units. For example, a caliper sonde produces a number which is proportional to the borehole diameter. To display this in mm or inches requires calibration coefficients to be applied.

The GVPL allows the user to both create calibration files for the sondes and to apply these calibration coefficients during logging.

The starting point to create a calibration file for a sonde is to build the sonde into a stack and enter the diagnostic screen, as described in previous sections of this manual. When displaying the sonde for which calibration is required, locate the channel name that is to be calibrated and place the cursor over the name. Now press the *right* mouse button and this screen will appear.

Calibration Value CAL	Data Value
100	23,500
200	255,600
300	525,300

Calibration Screen For A 2 Arm caliper

Actually, the screen shown is at the final stage of the calibration process. When the screen loads, the 3 boxes for “calibration value” and “Data value” will be empty.

#### Number Of Calibration Points

The software will apply an equation to the data in the form of equation (1) or equation (2);

$$calibrateddata = A_0 + A_1 \bullet SondeDataValue.....(1)$$

$$calibrateddata = A_0 + A_1 \bullet SondeDataValue + A_2 * SondeDataValue^2 .....(2)$$

Equation (1) is a 2 point straight line calibration, so if this is required the option “2 Point Calibration” should be selected.

Equation (2) is requires a 3 point non linear calibration, so if this is required the option “3 Point Calibration” should be selected.

The number of boxes available for data entry will change to reflect the number of points chosen here.

#### Averaging Period For The Calibration

When calibration is started, the system will accumulate data for a period which is selectable at values of 5, 20 or 100 seconds. For radioactive sondes, such as gamma

sondes, the 100 second interval should be selected. For most sondes, the averaging period of 5 seconds is adequate.

Select the period required by clicking the appropriate checkbox.

### Density Sonde Calibration

This selection is for calibrated density sondes, and is dealt with in a supplementary manual. Do not select either of these options unless a density sonde is being calibrated.

### Starting The Calibration

When the correct number of points and the correct averaging period is selected, place the sonde in the first calibration fixture. In this example, the caliper should be placed in the 100mm position of the calibration jig.


When ready, press “Start Cal 1”. The system will accumulate the data for the selected averaging period and display the result in the “Data value” box adjacent to the “Calibration value”.

Repeat this process for the three calibration points chosen. After the completion of the third calibration point (or the second if a two point calibration had been chosen) then the “Calculate” button will appear.

### Graphical Display Of The Calibration.

Press the “Calculate” button and the graph of the three (or two) calibration points will be drawn as shown. Most sonde responses are close to linear, and the deviation from linearity can be seen here in the example.

It is important to observe the graphical representation, as any errors in the procedure may be evident from this display.



In the example here, the result is almost certainly wrong and the reasons for this should be investigated. The example shown in “Calibration Screen For A 2 Arm caliper” above is reasonable and can be accepted.



## Saving Calibration Data To File

After the “Calculate” stage and the plotting of the graph, the “Save” button can be pressed. This will save the calibration data to the appropriate file.

The calibration data will be added to the file whose name is the concatenation of the sonde mnemonic and the sonde serial number with the extension .CAL. So, if this caliper (CALX) were serial number 1502 the calibration file name would be CALX1502.CAL. These calibration files are always stored in c:\gvsystem.

## Winch Parameters

The winch is an integral part of the logging system as it contains the depth measuring system and the cable tension measuring system. Both these parameters need calibration, and GVPL provides the software routines to achieve this calibration.

To gain access to these facilities, select **System->Winch control Panel** and the screen will appear.

The functions in this screen are boxed together logically, and will be discussed separately.

### Depth System Parameters

#### Winch version

The winch version is the version of the firmware running in the GeoVista logger and cannot be modified by the user.

#### Tension Units Kgs or Lbs

When a GeoVista winch with cable tension gauge installed is used, then the units for the display can be selected as either kilograms or pounds. The user should select the unit they feel most comfortable with. The selection has no impact on other parts of the system software.

#### Depth Units-feet Or Metres

The GVPL can operate in either Feet or Metres for the depth system. The user can select here which is required. Changing from one system is accomplished by simply selecting here, the GVPL will automatically change all the necessary conversion parameters.

**Depth System Parameters**

Winch Version:

Measure Wheel Circumference:

Depth Pulses Per Wheel Revolution:

☒ Reverse SE Sense

Tension Units:  
☒ Kgs  
☐ Lbs

Depth Units:  
☒ Metres  
☐ Feet

**Depth System Calibration**

Enter Depth Interval

**Set Depth Value**

Set Depth:

**Tension Bit Value**:

**Tension Calibrated**:

**Enter High Tension**:

**Enter Low Tension**:

**Direction**:  
☐ Up  
☒ Down

**Auto Depth Generation**  
☐ Auto Depth On\Off

Winch Control Panel

### Reverse SE Sense

If it is found that the depth decreases when the sondes are lowered downhole, then this can be reversed by changing the status of the checkbox here. On some systems, it is necessary to change the checkbox then press “Apply Parameters” and then reboot the GVPL software.

### Measure Wheel Circumference & Depth Pulses Per Revolution

These are the characteristics of the depth system on the winch.

The logger counts the pulses from the shaft encoder mounted on the winch, taking account of the direction of rotation, and computes the depth from this number and the circumference of the measure wheel.

$PPRev = Depth\_Pulses\_Per\_Wheel\_Revolution$

$Circ = Measure\_Wheel\_Circumference$

$DepthCount = Accumulated\_Depth\_Pulses\_From\_Encoder$

$$Depth = \frac{DepthCount}{PPRev} \bullet Circ$$

In the GeoVista system, both *PPREV* and *Circ* can be modified by the user. The ability to change the *PPREV* allows flexibility in interfacing to winches manufactured by other manufacturers, as does the ability to change the value of *Circ*.

Also the ability to modify *Circ* allows depth wheel wear to be compensated for.

The units for *Circ* are those selected in the adjacent selection panel i.e. feet or metres.

There is an automated process for calibrating the depth system, dealt with in the next section.

### **Depth System calibration**

The depth system comprises a measure wheel which turns when the cable passes over it. The measure wheel is coupled to a shaft encoder which produces the pulses as the wheel turns.

To calibrate the system, only the wheel rolling circumference value is required as the encoder number of pulses per revolution is fixed and known.

Calibration of the depth system is as follows;

- 1 Setup the winch and mark out a length of cable as accurately as possible, mark the measured distance with tape on the cable. The length of cable should be as long as practical. 10 metres should be considered a minimum for accurate results.
- 2 Pull the mark on the cable to a fixed reference mark and stop the winch.
- 3 Set the depth system to a positive value greater than the length of cable that will be pulled through the depth measure wheel (say, 200 metres)
- 4 Enter the length of cable that will be pulled through the depth system into the box Depth System Calibration>Enter Depth Interval.
- 5 Now press *Depth System Calibration>Start*. The text in this button will change to “Got nnnnnn”, where “nnnnnn” is the current count of the depth encoder pulses.
- 6 Now pull the cable through the depth measure system, ensuring that some tension is kept on the cable so no slippage occurs.

- 7 When the second tape mark reaches the reference point, stop the winch. Do not overrun the reference and reverse the direction, as this will cause errors. If the reference is overrun then start again from step 2.
- 8 When stopped at the second reference, press *Depth System Calibration>Stop*. The text in this button will change to “End nnnnnn”, again displaying the shaft encoder count.
- 9 Now press *Depth System Calibration>Apply*. The system will then compute the new measure wheel rolling circumference and display it in *Depth system Parameters>Measure Wheel Circumference*.
- 10 Check that the new value is reasonable (GeoVista winches are typically 0.4 metres circumference) and when satisfied, press *Depth System Parameters>Apply Parameters*. This will load the new value into the system files and hardware.


## Set Depth

Entering a value into *Set Depth Value>Set depth* and pressing *Set Depth Value>Apply Set Depth* will set the depth value.

There is another method of setting the system depth which is more convenient.

On the top screen, hold down the shift key on the keyboard and click the mouse anywhere in the lower part of the screen below the tool bars. This display will then appear.

In the window, the present depth will be displayed. The functions available are as follows;



Increase

This will increase the depth display by 0.01 metres each time it is clicked.

Decrease

This will decrease the depth display by 0.01 metres each time it is clicked.

Set Depth

Enter a depth into the window and press Set Depth will write the value to the depth display.

Zero The Depth

This will zero the displayed depth.

Set Stack Length

This checkbox will only appear if a stack has been selected. Checking this box will transfer the stack length into the window, and then press Set Depth to set this as the system depth. The value of this is if the top of the sonde stack has been set to the depth reference, then the correct depth for tool zero is the stack length, or the bottom of the stack.

### **Auto Depth generation**

This facility is available to assist in sonde checking, and allows for the generation of depth events without turning the winch.

To activate, click on *Auto Depth Generation>Auto Depth On\Off* and select the required direction by selecting *Direction>Up* or *Direction>Down*. The speed of the simulated depth can be controlled by moving the slider in the same panel.

### **Cable Tension System calibration.**

The cable tension signal is reported to the GVPL as a raw value, and calibrated in the software. This raw data value is displayed in the window “Tension Bit Value” as seen in the winch control panel screen.

To calibrate the system, follow this procedure

- 1 Ensure that the correct tension units have been selected.
- 2 Setup the winch so two different weights can be conveniently attached to the cable. Choose two weights suitable for the winch and cable in use, representing typically the range of tensions to be expected in operation.

- 3 Attach the lighter of the weights, and enter the value of the weight into the “Enter Low tension” box. Now lift up the weight slowly, and while in motion press the gauge icon adjacent to the “Enter Low tension” box. An elapsed time bar will appear for a few seconds.
- 4 Now attach the heavier weight, entering the weight into the “Enter High Tension” box. Lift up the weight again and press the icon adjacent to the “Enter High Tension” box.
- 5 On completion, the “Apply Calibration” button will become available. Press this to calculate the new tension gauge calibrations. The calibration will now be stored.
- 6 Check that the displayed tension is correct. Change back to the lighter of the weights and ensure that the correct reading is obtained.


The calibration coefficients are stored in the logger box, and also in one of the system database files. These coefficients can be retrieved from the system file by simply pressing the “Load From Sys File” without going through the procedure described above.

## Cable Tension Alarm

During logging operations, the operator should keep a close watch on the cable tension display. Either over tension (sondes stuck logging up) or under tension (sondes hang up while going down) can lead to problems.

On GVPL version 6.55 and later what is conventionally termed a differential tension display is available. A more accurate description would be a delta tension display.

This display is reset by the user by double clicking the display of differential tension. A sample is shown here.



When the operator resets the differential tension display, the software will store the current value of the cable tension. As the cable tension increases, then the green bar as shown will move towards the right. If the cable tension decreases then the display will move towards the left, and will be drawn in red. Thus the user will have a quick visual indication of which way the tension is changing.

Clicking the “Differential Tension Reset” will return the display to the centre.

To activate this display, an entry in the c:\gvsystem\gv\_sys.ini file is required. Open this with notepad and add this section at the end of the file;


[Tension Alarm]  
CommPort= 12  
Span\_0=5  
Span\_1=10  
Span\_2=20  
Span\_3=30  
Span\_4=40  
Visual Display=On  
Audio Alarm=On  
Span= 10  
Reset Value= 10

Note that the “Span” entries represent the total span of the differential display. These values can be changed by the user. While running, using the mouse to “right click” the differential tension display the different span selections can be made.

An audible alarm unit can be purchased from GeoVista that alerts the operator when the differential tension display gets to either the maximum or minimum end of the display. This unit simply plugs into a spare USB port on the logging computer.

## Tools Menu


The GVPL software allows some log file manipulation functions which can be useful. These are accessed from the



The tools are accessed by **Tools>Log File depth Shift** and **Tools>Log Splice**, as shown above. These will be discussed separately.

## Log File Depth Shift

On selecting the option, the log file select menu will be presented, the user should select the log file (\*.RDF) that is to be processed. After selection, the screen will appear as below.



The selected filename and path will appear in the window “Selected File name”. Note the button annotated “Save Safe Copy To C:\ClientsLogs\bh\_test.SFT”. Pressing this will create a safety copy of the log file with the same name but extension .SFT in the same directory, in this case “C:\ClientsLogs\bh\_test.SFT”. This allows a recovery position if some processing errors occur.

Also will appear the depth wheel parameters, the circumference and the number of pulses per revolution. These can be edited and applied by pressing “Write Edit Values”.


The whole log can be shifted in depth by entering the depth shift required in the “Enter Depth Shift” box, always entering a positive number, and selecting if the new log file needs to be deeper or shallower. Press “Apply” will cause the shift to be made.

### Log File Splice

Often two runs are made in the same well, the second run being deeper. The log files obtained from these different runs can be splice to create a single log file that can be replayed.

To achieve this, select **Tools>Log Splice**. The screen will appear as below;





Here the user can browse for the two input files File A and File B. The file to be created, the concatenation of File A and File B, is named by entering the path in name in the lower text box.

The depth at which the splice is to be made is chosen and entered into the “Splice Depth” window. Pressing “Start Splice” will merge the File A and B into the output file. The header created for the output file is copied, without modification, from File A.HDR.

## Density Logging With The GeoVista System

The GeoVista logging system is capable of producing density logs, from density sondes, calibrated in grams per CC while logging. The methods employed are described here.

### Enabling & Disabling The Density In Grams\CC

Note that some applications require that raw CPS be displayed on the log. This can be achieved by switching OFF the density function formers.

Locate the file \gvsystem\gv1sonde.ini and open it with notepad. Search for the CDL sonde entry and locate this section;

```

Curve#1==
Curve# 1=LSD
Depth Offset# 1=0.20
Unit Name# 1=G\CC
Packet Length# 1=2
Frequency Based# 1=Yes
TimeBase Channel# 1=No
Scale# 1=Linear
LH_Value# 1=0
RH_Value# 1=20
LH_POS# 1=TK2
RH_POS# 1=TK3
Coding# 1=8388863
Curve Width # 1=0
FW# 1=0.15
Apply LS density Algorithm# 1=Yes
Calibration Routine# 1=0
Curve#2==
Curve# 2=SSD
Depth Offset# 2=0.08
Unit Name# 2=G\CC
Packet Length# 2=2
Frequency Based# 2=Yes
TimeBase Channel# 2=No
Scale# 2=Linear
LH_Value# 2=0
RH_Value# 2=20
LH_POS# 2=TK2
RH_POS# 2=TK3
Coding# 2=16711680
Curve Width # 2=0
FW# 2=0.15
Apply SS density Algorithm# 2=No
Calibration Routine# 2=0

```

The lines of interest have been highlighted. In this application the LSD has the density calibration into grams\CC enabled (**Apply LS density Algorithm# 1=Yes**) while the SSD detector will not be converted into grams\CC (**Apply SS density Algorithm# 2=No**).

Any combination of Yes & No is allowed. Note that after a log is recorded, then these (highlighted) phrases appear in the header file. These can then be edited to replay the log in different formats.

Master Calibration.

The first step in setting up the system is to generate the master calibration count rates. These are the count rates obtained in the test fixtures , Aluminium and water, obtained from the master sonde and source.

For the moment, assume that only one logging source and sonde available . The procedure is to nominate the density sonde as the master sonde. This sonde is then placed, in turn, onto the Aluminium block and into the water vessel, with the source attached.

The count rates for both long and short detectors should be accumulated over a 300 second period and recorded. The “Average” button on the diagnostic screen can be used for this.

These are entered into the system file GV\_SYS.INI located in the \gvsystem directory on the logging computer. Open this file with an ASCII editor and locate the section as shown here;

```
[Density Algorithm Coefficients]
SS_A=25.0292
SS_B=-2.8896
LS_A=5.4787
LS_B=-0.6359

LS_WaterPoint=1109.0
LS_AluminiumPoint=79.0
SS_WaterPoint=4060.0
SS_AluminiumPoint=2270.0

LS DeadTime (microseconds)=1.1
LS Dead Time CorrectionON=Yes

SS DeadTime (microseconds)=1.1
SS Dead Time CorrectionON=Yes

Aluminium Density(gm\cc)=2.70
Water density(gm\cc)=1.02
```

Then enter the values noted into this file in the locations shown below;

The Count Rate Measured;	Enter Into;
LSD in water calibrator	LS_WaterPoint
LSD in Aluminium	LS_AluminiumPoint
SSD in Water Calibrator	SS_WaterPoint
SSD in Aluminium	SS_AluminiumPoint

Note that the values of the densities of the calibration points used (Aluminium and water) are also entered into this file. The values shown are normally correct for the block supplied, but may be changed. For example, if the user wished to use Magnesium instead of water, the Magnesium values can be substituted for the water

values. Do not change the text to the left hand side of the “=” sign, just enter the Magnesium values and enter

```
Aluminium Density(gm\cc)=2.710
Water density(gm\cc)=1.7
```

Where 1.7 gm\cc is the density of the Magnesium block available. The fact that the text incorrectly describes the second block will have no impact on the results.

### How Is The Master Calibration Applied?

When the GeoVista software is started, the values in this section of GV\_SYS.INI file are read and coefficients calculated. These coefficients are used to calculate density from the measured count rates, one set of coefficients for each detector.

The coefficients are used as;

$$\text{LSD Density} = \text{LS\_A} + \text{LS\_B} * \log(\text{LSD Count Rate}) \dots\dots\dots (1)$$

$$\text{SSD Density} = \text{SS\_A} + \text{SS\_B} * \log(\text{SSD Count Rate}) \dots\dots\dots (2)$$

Where both results are in grams per CC. Note that the values of A and B for both the long and short detectors are written to the GV\_SYS.INI file. These are for convenience only and are never read by the software. Note that throughout the density calibration, natural logarithms are used rather than base 10 logarithms.

### Sonde Normalisation

Not all sondes are identical, and sometimes different logging sources are used. To get around this and still use the same set of coefficients (LS\_A, LS\_N, SS\_A and SS\_B) for each sonde, the sonde in use is normalised to match the master calibration data. This is achieved using the usual sonde calibration routines offered by the GeoVista software. This procedure is started from the diagnostic logging screen by placing the mouse cursor over the required channel and clicking the right mouse button. The calibration screen will then be displayed.

On this screen is a “Density Calibration” box with two options, “LS Detector” and “SS Detector”. Clicking one of these will preload the calibration points in the “Calibration Point” windows with the master calibration values that have been read from the GV\_SYS.INI file. This is a convenience so that the user does not have to remember awkward numbers.

With the sonde in the appropriate calibration fixture, start the calibration point acquisition in the usual manner. Select 100 seconds for the average period.

On completion of the two points, press “Calculate” and “Save”. The coefficients to normalise the current sonde to the master sonde count rates will then be written.

Of course, if this sonde is the master sonde then the count rates should be similar.

A sample screen is shown below where the LSD normalisation procedure has been initiated.

The screenshot shows the 'Calibrating Sonde CDL' window. It features three main sections on the left for configuration: 'Select Number Of Points' with radio buttons for 2, 3, and 4 point calibration (2 is selected); 'Select Average Period' with radio buttons for 5, 20, and 100 seconds (5 is selected); and 'Density Calibration' with radio buttons for LS and SS detectors (LS is selected). The center contains a table with 'Calibration Value LSD' and 'Data Value' columns, showing two rows: 'Water Point' (1109.0, 1121.50) and 'Aluminium Point' (79.0, 82.50), each with a 'Start Cal' button. A graph in the center shows a linear trendline. On the right, there is a text box for 'A0' with the value '-2.78537055E+00', and three buttons: 'Calculate', 'Save', and 'Exit'.

	Calibration Value LSD	Data Value	
<input checked="" type="radio"/> 2 Point Calibration	1109.0	1121.50	Start Cal 1 Water Point
<input type="radio"/> 3 Point Calibration	79.0	82.50	Start Cal 2 Aluminium Point
<input type="radio"/> 4 Point Calibration			

Select Average Period:  
☒ 5 Seconds  
☐ 20 Seconds  
☐ 100 Seconds


Density Calibration:  
☒ LS Detector  
☐ SS Detector

A0= -2.78537055E+00

Calculate  
Save  
Exit

## Data Flow While Logging

A schematic of the data flow while logging is shown below. Details such as depth offsets and filtering are not included for clarity, just those points pertinent to density logging are shown.



There are two stages, the normaliser and the density function former. The use of the coefficients can be clearly seen. There are two identical processes in operation, one each for the short spacing and long spacing.

On the diagnostic screen, the display for the SSD and LSD will be in CPS when the “calibrate” function is not selected. When pressed, the software will automatically apply the normalisation coefficients and density in gm/cc.

## Notes On The Calibrators.

The large Aluminium (250mm \* 250mm \* 500mm) calibrator supplied by GeoVista has a cut out in the top surface which accommodates the sonde. Also a clamp at the rear of the block to hold the sonde firmly in place. This should be adjusted so that there is no movement of the sonde. The surface of the block should be cleaned before use.

The size of this block is such that it is effectively infinite (that is, if you made it bigger the count rates would not change) and is a master calibration point.

The water calibration tank should have at least 500mm water depth and 500mm of water in front of the detector assembly (the side away from the caliper arm). There should be at least 300mm of water behind the sonde., but ideally it would be symmetrical.

An optionally supplied calibrator is the light weight field jig. This is easily handled and can be placed onto the sonde by one person. This is not a calibrator, but rather a check jig to determine if some sonde failure, for example, a broken crystal, has occurred since the last master calibration.

The procedure is to perform the master calibration then place the sonde in the field jig and record a time log. Ideally, the sonde should be supported off the ground and the detector assembly facing upwards.

In the field the sonde is placed in the jig and the response compared with that obtained in the shop. Any significant deviation indicates that there is a problem with the sonde which should be investigated.

## **Version 2 Logger & Sonde Communications Control**

In March 2008, GeoVista released the version 2 logger. From the users point of view, the main advantage is the ability to control the sonde communication parameters. This allows for correct operation on longer logging cables.

With the earlier generation loggers, the main reason that communications was compromised on longer cables was that the sonde address pulses were attenuated leading to an incorrect address reception in the sonde.

To fully utilise these new functions, an oscilloscope is required, although the improvement is so significant that successful communications is usually achieved without this.

Presented here are some sample waveforms recorded on 2,600 metres of 3/16" monocable. An oscilloscope was connected at the cable head end and the waveforms recorded.


To utilise these functions, GeoVista Platform Logger software Version 6.21 or higher is required. This version will operate with all GeoVista USB loggers, the communication control options will not be available on earlier loggers.

Selection Of The Control Window.

Access is via the existing tools menu and is selected as;



This will open the control window;




Here are presented typical values that will operate correctly in most situations. On shorter cables, selecting “Low Drive” may be advisable.

Below is shown the sonde address reception with different settings. The settings are recorded below the scope shot.


It should be noted that for good reception all the positive peaks need to cross the threshold of 1 Volt, seen as the horizontal blue line.

All the parameters discussed here are stored in the logger and are recalled when the software is restarted.







**Scope Shot Address Pulse Width = 40 Address UnderDrive = 0. High Drive selected**




**Scope Shot** Address Pulse Width = 20 Address UnderDrive = 0. High Drive selected



Scope Shot Address Pulse Width = 20 Address UnderDrive = 0. Low Drive selected



**Scope Shot Address Pulse Width = 60 Address UnderDrive = 0. High Drive selected**



Scope Shot Address Pulse Width = 60 Address UnderDrive = 10. High Drive selected

### Set Current Limit

This allows the user to set the value at which the sonde power supply, in the logger, will trip out at. A visual indication is given when the sonde power trips. This value can be adjusted up to a maximum of 250 milliamperes.

### Set Threshold

At surface, the sonde pulses are discriminated against a DC level. This can be controlled from here. The value shown will operate in most cases.

### Software Modification Record

5.78 March 2004 added the exp function in user functions

5.80 July 2004 added wiggle display on sonic replay and allow resizing of the display on replay. Also added the logarithmic grid display option on replay (only)

5.81 added the response to the shaft encoder error from the latest boards WDU4



- added the depth shift of the sonic files to the log edit menu
- modified the SGAM Ascii file format.
- allowed creation of a LAS file with only those curves currently displayed.
- Added GET DEPTH and GET TENSION to the user functions
- 5.82 April 2005 Added the SEG2 file format export of full wave sonic files
- Also forced calibration to be ON when the diagnostic screen is enabled
  
- 6.26 with new sonic completed. Dec 2008
- 6.27 Added the scaling to the SEG2 wiggle output, controlled from the GV\_SYS.INI file A0 & A1
- 6.28 Fixed the problem where zero CPS on the long spacing density caused a zero density to be output.
- 6.32 Added the Array Sonic sonde. Fixed problem where it only wrote the first 3 of '
- 6.33 Added function ExportSngSonicNormalisedWiggleAsSEG2Format to conform with WellCad requirements for equal depth samples and equal depth interval for SEG2 files
- 6.34 added the LAS auto creation and the "double click on RDF\HDR" to open in replay mode
- 6.35 Added the DeadTime controls to the fullwave sonic sonde.
- 6.36. Added user entered depth offset when creating AutoLAS file ' from user supplied Excel\_CSV file when fields match.
- 6.37 Added writing the SGAM windows into the header. Also preselected the temp stab flag to be on
- 6.38 Fixed some of the automatic LAS file generation bugs
- 6.39 Allowed the Verticality plot when the VECS sonde was used
- 6.40 Corrected the incorrect filename extensions applied to the export of SEG2 & Ascii files.
- 6.41 fixed the log(0) on the density calculation routine
- 6.42 added the CalcVert function to the userfunctions.
- 6.43 Added the K U Th calculation on the diagnostic screen and saving to the Ascii file recorded.
- 6.44. Added winch parameter selection. Fixed bug where the Cypress USB chip logger failed with SGAM
- 6.45 added the Gyro functionality.
- 6.47 Added the GvNSonde.ini functionality
- 6.48. Added the HRSG sonde. Also the FEET flag in the SEG2 file generation
- 6.49 to fix some remaining HRSG issues. Added the change depth units to file depth shift toolbar
- 6.50 Added the 4 receiver sonic sonde
- 6.51, corrected the SEG2 file name extension as mentioned. Added the log disclaimer to the header print out
- 6.52 Added the extras for the ASNC sonde 4 \* RX version

## **Manual Modification Record**

To Version 5.0 June 2003. Added more screen shots & improved index.

To Version 5.1 September 2003. Added Video typewriter description

To Version 5.2 Feb 2004. Included density manual.

To Version 5.3 July 2004. Included comments on sonic file Ascii export

To Version 5.4 May 2005. Included comments on sonic file SEG2 export

To Version 6.0 March 2008. Included the cable communications description.

To Version 7.1 August 2009 Included the Automatic LAS generation & Windows association.

To Version 7.2 March 2011 Added the header entries association with LAS fields.

To Version 7.3 March 2012 Added the log disclaimer section.

To Version 7.4 July 2012 Added the differential tension display section.